Canon

## PowerShot G3X

## Camera User Guide

- Make sure you read this guide, including the "Safety Precautions" (Q15) section, before using the camera.
- Reading this guide will help you learn to use the camera properly.
- Store this guide safely so that you can use it in the future.

- Click the buttons in the lower right to access other pages.
- ▶: Next page
- Previous page
- ☐: Page before you clicked a link
- To jump to the beginning of a chapter, click the chapter title at right.

Before Use	
Basic Guide	
Advanced Guide	
	Camera Basics
	Auto Mode / Hybrid Auto Mode
	Other Shooting Modes
	P Mode
	Tv, Av, M, C1, and C2 Mode
	Playback Mode
	Wi-Fi Functions
	Setting Menu
	Accessories
	Appendix
Index	



© CANON INC. 2015

CDD-E635-020

ENGLISH